

Questions or Comments

For questions or comments regarding this or other eKids products, please visit our website: www.ekids.com

Maintenance

It is important to keep the unit as dry and clean as possible. Clean the unit with a soft cloth moistened only with mild soap and water. Stronger cleaning agents, such as thinner or similar materials are not recommended, as they may damage the surface of the case. Do not allow dirt, sand, small particles, water or other liquids to enter the toy's casing

Important Safety Instructions

Please heed all warnings, read and follow all instructions and keep these instructions handy for future reference.

- Do not use this product near water.
 Do not block any ventilation openings. Install in accordance with the manufacturer's nstructions 3. Heat - This product should be situated away from heat sources such as radiators, heat
- registers, stoves or other appliances (including amplifiers) that produce heat. Only use attachments/accessories specified by the manufacturer
- Damage Requiring Service This product should be serviced by qualified service personnel Objects have fallen into or liquid has been spilled into the enclosure
- The unit has been exposed to rain. The unit has been dropped or the enclosure damaged
- The unit exhibits a marked change in performance or does not operate normally.
 No naked flame sources, such as lighted candles, should be placed on this product. Attention should be drawn to the environmental aspects of battery disposal. Many electronics retailers now recycle batteries and other electronic components at no charge. To find a
- drop-off location near you, visit www.call2recycle.com
- 8. This product is suitable for use in tropical and/or moderate climates

WARNING

To reduce the risk of fire or electric shock, do not expose this product to rain or moisture. Do not dispose of batteries in fin

FCC Information

Folded

- This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device complies with Part 15 of the FCC Rules, operation is subject to the following
- (1) This device may not cause harmful interference, and (2) this device must accent any interference received, including interference that may cause undesired operation.
- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment
- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential

installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver Connect the equipment into an outlet on a circuit different from that to which the receiver is
- connected · Consult the dealer or an experienced radio/TV technician for help.

ISED Information

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: This device may not cause interference.

- (2) This device must accept any interference, including interference that may cause undesired operation of the device.
- The device comply with ISED RF exposure requirement, users can obtain Canadian information on RF exposure and compliance. Any Changes or modifications not expressly approved by the party responsible for compliance could

void the user's authority to operate the equipment.

Cet équipement est conforme aux limites d'exposition aux radiations IC CNR-102 établies pour un ement non contrôlé

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes

(1) L'appareil ne doit pas produire de brouillage:

(2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

L'appareil est conforme aux exigences d'exposition RF ISED, les utilisateurs peuvent obtenir des informations canadiennes sur l'exposition aux RF et la conformité. Tout changement ou modification non expressément approuvé par la partie responsable de la

conformité peut annuler l'autorité de l'utilisateur à utiliser l'équipement.

purchased. Should this fail to resolve the matter and service still be required by reason of any defect or malfunction during the warranty period, eKids will repair or, at its discretion, replace this product without charge. This decision is subject to verification of the defect or malfunction upon delivery of this product to the Factory Service Center authorized by Customer Service.

If service is required, please contact Customer Service at ekids.com/support to obtain a Return Authorization Number and shipping instructions. A copy of the sales receipt is required to validate in-warranty coverage. Disclaimer of Warranty

NOTE: This warranty is valid only if the product is used for the purpose for which it was designed. It does not cover (i) products which have been damaged by negligence or willful actions, misuse or accident, or which have been modified or repaired by unauthorized persons; (ii) cracked or broken cabinets, or units damaged by excessive heat; (iii) damage to digital media players, CD's or tape cassettes (if applicable); (iv) the cost of shipping this product to the Factory Service Center and its return to the owner. This warranty is valid only in the United States of America and does not extend to owners of the product other than to the original purchaser. In no event will eKids or any of its affiliates, contractors, resellers, their officers, directors, shareholders, members or agents be liable to you or any third party for any consequential or incidental damages, any lost profits, actual, exemplary or punitive damages. (Some states do not allow limitations on implied warranties or exclusion of consequential damages, so these restrictions may not apply to you.) This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. Your acknowledgment and agreement to fully and completely abide by the above mentioned disclaimer of warranty is contractually binding to you upon your transfer of currency (money order, cashier's check, or credit card) for purchase of your eKids products.

> © 2023 eKids, LLC Questions? Visit www.ekids.com

Printed in China

DP-B12-091523-A

Installing the Batteries

ATTENTION: Batteries should only be installed by an adult.

The unit comes with batteries already installed. These batteries are meant for in-store demonstration use only, and should be replaced with fresh batteries. To replace the batteries at home:

- 1 Use a Philips screwdriver to open the battery compartment door.
- 2 Install 3 "AA" LR6 batteries into the compartment, making sure that the + and - polarities match the diagram printed inside.
- 3 Close the battery compartment door and tighten the battery door screw. Don't over tighten.

ON/OFF Switch

The unit is shipped in ON position (with Try Me feature). To use the unit, slide the switch to OFF position, then to ON position.

-0

Playing with the Microphone

Bluetooth Pairing

- Turn on your Bluetooth device and enable Bluetooth mode (check in Options or Settings).
- Slide the switch on the microphone to the ON position.
- Press the **\$** Button to enter Bluetooth pairing mode.
- Using your Bluetooth device, select the Bluetooth pairing name for your product "ekids B12DP"
- "Connected" will sound to confirm once your device is paired. Put your Bluetooth device in play mode to play audio.
- To manually pair, press and hold the **X** Button for 2-3 seconds.

Sing a Song

• Press and hold the button to amplify your voice while you sing!

Built-in Song

• Press the 🎵 button to play built-in music!

Echo Effects

Press the (i) Button to turn echo effect ON/OFF

Note: While unit is streaming Bluetooth audio, if no button is pressed, unit will automatically shut off after 5 mins.

Bluetooth will disconnect while built-in song is playing. Press the Bluetooth button to return to Bluetooth mode.

Front

CAN ICES-3 (B) / NMB-3(B) Limited 1 Year Warranty Information eKids, LLC warrants this product to be free from defects in workmanship and materials, under normal use and conditions, for a period of one (1) year from the date of original purchase. Should this product fail to function in a satisfactory manner, it is best to first return it to the store where it was originally

```
Back
```

For the Best Possible Performance

- Only use the recommended/supplied batteries or equivalent. Use alkaline batteries for longer life.
- Do not mix old and new batteries, and do not mix alkaline, carbon-zinc or rechargeable nickel-cadmium batteries.
- Insert batteries with proper polarity (+/-) as indicated.
- Remove exhausted batteries from product.
- Recharge rechargeable batteries under adult supervision.
- Do not attempt to recharge non-rechargeable batteries.
- Do not open batteries or heat them beyond normal ambient temperatures.
- To prevent battery leakage or damage remove batteries from a product if it will not be used for a month or longer.
- Use extreme caution handling leaking batteries (avoid direct contact with eyes and skin). If battery leakage comes in contact with eyes, IMMEDIATELY flush the eye with lukewarm and gently flowing water for at least 30 minutes. If skin contact occurs, wash skin with clean water for at least 15 minutes. Seek medical attention if any symptoms OCCU
- Store in cool, dry, ventilated area away from hazardous or combustible material.
- Do not dispose of batteries in fire.
- Follow applicable laws and local regulations for the disposal and transportation of batteries.
- Batteries must be disposed of separately at your local waste recycling center.

