Limited 90-Day Warranty Information eKids, ILC yearants this product to be free from defects in workmanship and materials, under normal use and conditions, for a period of 90 days from the date of cristical purchase.

Smooth for product fall to function in a satisfactory manner, it is best to find return it to fine sterp where it was originally prunchased. Should this fall to microler fine motive crail service still be required by respect of any delect or reduced making the variously period, eldul will report or, at its discretion, replace this product without chasps. This decision is subject to realization of the delect or reduction upon delivery of this product to the Todary Service Center orientated by Costomer. Eservice is required, please call Customer Service at 1-800-288-2792 to obtain a Return Authorization Number and shipping.

DISCENSION or Visitions, Which and Will be product is used by the purpose for which it was designed. It does not cover (it) products which have been obtained by registers or willful action, return or accident, or which have been readled or septical by readmixing beginning. If or called or beginning the readmixing person, it (is caused or beginning that or with designed by the case when the lift designs to digital media polyme, CDI or taps cases lift applicability. (iv) the case of shapping this product to the fractory Service Center and it is when to the considerability.

in states to the context.

The security is useful ordy in the United States of Premising and does not extend a context of the security in collection for the property of the context of the security in collection for the context of the security of the secu other rights which vary from state to state. Your acknowledgement and agreement to fully and completely abide by the above mentioned disclaimer of warranty is contractually brinding to you upon your transfer of currency known yorder, contracts achieve, or overall condition perchase of your

Consumer Product Safety Guide IMPORTANT SAFETY INSTRUCTIONS


When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. However, improper use can result in potential electrical shock or fire hazards. Please read all safety.

- reference. Take special note of all warnings listed in these instructions and on the unit. Water and Maisture - The unit should not be used near water. For example: near a bathub, washbowl 2. Ventilation - The unit should be situated so that its location or position does not interfere with its proper
- verification openings. Also, it should not be placed in a builtin installation, such as a bookcase or cabinet, which may impede the flow of air through the verification openings.
- 3. Heat The unit should be situated away from heat sources such as radiators, heat registers, stoves or
- 4. Power Sources The unit should be connected to a power supply only of the type described in the ctions or as marked on the appliance.
- 5. Power-Cable Protection Power supply cables should be routed so that they are not likely to be walked on ar pinched by items placed upon or against them. It is always best to have a clear area from where the cable exits the unit to where it is plugged into an AC socket.
- 6. Cleaning The unit should be cleaned only using a warm damp cloth. Do not use solvents, etc. 7. Objects and limit Fatry - Care should be taken so that objects do not full and limits are not sailed
- into any openings or vents located on the product.

 8. Attachments Do not use attachments not recommended by the product manufacturer.
- 9. Lightning and Power Surge Protection Unplug the unit from the wall socket and disconnect the periods of time. This will prevent damage to the product due to lightning and powerline surges.
- 10. Overloading Do not overload wall sockets, extension cords, or integral convenience receptacles as this can result in a risk of fine or electric shock.
- 11. Damage Requiring Service The unit should be serviced by qualified service personnel where
- A the power supply cable or plug has been damaged.
- C. the unit has been exposed to rain.

 D. the unit has been dropped or the enclosure damaged.
- E. the unit exhibits a marked change in performance or does not operate normally.
- 12. Periods of Noruse If the unit is to be left unused for an extended period of time, such as a month
- or longer, the power cable should be unplugged from the unit to prevent damage or corrosion. 13. Servicing – The user should not attempt to service the unit beyond those methods described in the
- user's operating instructions. Service methods not covered in the operating instructions should be

Questions? Visit www.ekids.com or call 1-800/288-2792 Tall Free



B27

FCC Information FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

- This device complies with Part 15 of the PCC Rules, operation is subject to the following two conditions: (1) This device may not couse harmful interference, and (2) this device must accept any interference received, including interference that may cause undestined appendix.
- Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the PCC Rules.

These limits are designed to provide reconcible protection against hormful interference in a residential installation. This equipment generates, uses and an educities and in recondiscion of high interference in addition considerates with the interference in addition considerates. However, there is no government that interference in a particular installation. If this equipment does cause hormful interference in order or relations recognition, which can be determined by uning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following Integrands

- Recrision is relocate the secesiving antenna.

- Increase the separation between the equipment and secesiver

- Increase the separation between the equipment and secesiver

- Consect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consect the decider or an experienced adde/TV schriction for help.

CAN ICES, 3 (B) /NIMB, 3(B)

IC Statement

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS 102 RF exposure, users can obtain Canadian information on RF exposure and compliance to dispositif rencontre it exemption des limites courantes divolucation dars la section 2.5 de RSS 102 et la conformité à l'exposition de RSS 102 rt, utilisateurs peut obtain? Information canadianne sur l'exposition et la conformité de rf.

IMPORTANT

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: [1] This device may not cause interference, and

12 This device must accept any interference, including interference that may cause undesired operation of the device. Le présentapogreilestonforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de

ionne. L'exploitationestautarisée aux deux conditions suivantes:

(1) l'appareil ne deit pas produire de brouillage, et
2) l'utilisateur de l'appareillati accepter tout brouillageratioélectriquesubi, mêmesi le brouillagesst
susceptible d'encompromette le fonctionnement.

Declaration ID: BO21180

If you have any question regarding the operation or use of this product, please visit www.ekids.com to

Thank you for purchasing the iHome B27. This product is designed to provide high quality wireless sound

This instruction booklet explains the basic operation and care of the unit. Please read them carefully and

To learn more about this and other iHome products, please visit us online at www.ihome.com

for your iRed. iPhone. iRed. commuter. PD& or other Blustooth media desires.

Internal Rechargeable Lithium-ion Battery

WARNING/DISPOSAL OF LINIT

- WWENIAMO/DISPOSAL OF UNITY

 Remail of NCT integrate to charges the bottery yourself. If the bottery has died and you do not want us to replace
 you better, you should follow the disposal instruction below.

 Remail of the content of the property of the disposal of bottered yelloctricis, if these one no food migrations concerning battery/electronic disposal,
 please disposal of the diver in or vasies the forelectricis of them. Many electronics retailers now recycle batteries and other electronic components at no charge. Check to see
- A woming first batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sarshine, like or the like.

CAUTION The battery used in this device may present a risk of fire, explosion or chemical burn if

Never use or charge the battery if it appears to be leaking, discolored, deformed, or in any way abnormal.

- electrolytic substance.

 Always confirm that the temperature is 5°C 35° C (41° · 95° Fahrenheit) before you charge the battery.
- New groups and the facilities and the facilities are seen as the facilities are consistent and the faci

- . Place the unit on a level surface away from sources of direct surlight or excessive heat Protect your furniture when placing your unit on a natural wood and lacquered finish. A clath or other protective material should be placed between it and the furniture.
- Clean your unit with a soft cloth moistened only with mild soap and water. Stronger cleaning agents,

Power/Charging/Pairing indicator LED USB charging cable

__ALIX/\$ /OFF Switch

Using the B27

Using the B27

charge input jack Imicro USB Conn

Note: The aux position is for AUX-In audio only. The \$ position is for Bluetooth audio only. When not in use, slide Power Switch to the OFF position to save battery power.

. Connect the micro USB plug to the micro USB charaing part on the back of the unit

Charge via USB AC adaptor, computer USB port, or other powered USB por

2. Connect the standard USB plug end of the cable to a power USB part on a computer or other USB The Power/Charging/Pairing Indicator on the front of the unit glows red steadily while the unit is charging and tuns OFF once the unit is fully charged. The Power/Charging/Pairing Indicator will

Pairing is the setup process to introduce your Bluetoofhropable device to the B27. Once your device is d, the B27 can recognize it and you can play your audio through it.

2. Stide the about \$7.00 Sweet on the cack of the little is an \$2, sweet or person.

2. Stide the about \$7.00 Sweet on the cack of the B27 searches for a connected device for 10 seconds. After 10 seconds, After little sweet of the cack will fash blue and red and a tone will sound, indicating paining mode.

3. "Home B27" should appear in your device's Bluetoofs menu. If "Not Paired". "Not Connected" or similar

If pairing is successful, a tone will sound and the Bluetooth indicator light will glow solid, indicating the B27 is ready to also music. There should also be as indication on your device. If no device is successfully

paried within 2 minutes the B27 will default to previous mode. Once the B27 is paired to a device, it will attempt to autolink when the device is within range (about 30 feet).

Make sure your Bluetooth device is fully charged. Turn on your Bluetooth device and make it "discoverable" by turning on Bluetooth mode (check in Options or Settings).

2. Slide the aux/\$/off Switch on the back of the unit to the g position (center). A tone will

The series of th

+5-0s- **-**

Meet Your R27

Aurein -

Charaina the Unit

Pairing Your Device

device's keypad.

CHARGE UNIT BEFORE USE

Using the B27

Pairing with a Different Device

When the speaker is in \$ mode, it will automatically link with the previously pained Bluetooth device as florg as that device is all within range (approx. 30 feet). So, to pair with a different device you must turn oil the Bluetooth capability of the otheraby partied device.

Plavina Audio Via Bluetooth

1. Move the aux/\$/aff Switch to the Bluetooth position (center) to listen to audio streamed wirelessly

How your pared iPad, Phone, iPad or after Bluetooh device.

The Power/Charging/Pairing Indicator Light on the floret of the unit will flash blue and a tone will

- When done listening, move the aux/\$/aff Switch to the aff position (right) to turn the unit off.


Using the B27

Playing Audio via Aux In 1. Connect a standard 3.5mm audio cable (not included) to the **aux-in** lack on the back of the unit and

- connect the other end to the headphone or linerast jack on your audio device.

 Move the aux/ 3 /dff Switch to the aux position [lift] to laten to audio via aux in. The
 Power/Changing/Pairing Indicator Light on the fort of the unit will glow blue.

 Power on the audio device and use the control on the device to play or praise audio, navigate tracks.
- 4. When done listening, move the aux/4/off Switch to the off position [right] to turn the unit off.



Troubleshooting

Unit doesn't respond (no power)

Check that all connections are correct and properly plugged in.
Make sure your device is properly paired with the B27.
Make sure free aux/\$/aff Switch switch is not in the aff (right) position.

The sechargeable battery in your speaker can be replaced only by eKids Consumer Repair

Trouble pairing device/computer with B27

- Bluetooth implementation varies depending on your device's hardware and operating system. Please see our website for updates on pairing. When the speaker is in \$ mode, it will automatically link with the last previously paired Bluetooth device if the device is still within range (approx. 30 feet). To pair with a different device you must turn off Bluetoch capability on the already paired device, or take it out of range.
- Four device does not autofish, when within range of a Blastoch autofia is low, sepair the device. To do so, first delate the 227 from your Blastoch devices ments. Move the out/3/off Switch on the unit to the 3 position (ported) to begin positing lake page 3 for origining details).

 Motte save your device is working properly. Check your devices in manual for details on Blastoch.
- For further information and to see the latest instructions, visit www.ekids.com/support